



Notes:

- 1- Locate valve box in planting area.
- 2- Wrap valve box with min. 3 MIL thick plastic and secure it using duct tape or electrical tape.
- 3- All threaded connections to be made using teflon tape.
- 4- All changes in elevation to be made using Sch. 40 PVC 45° elbows.



BALL VALVE 4" AND LARGER