

Notes:

- 1- Install gate valve per manufacturer's specifications and recommendations.
- 2- Valve box shall be wrapped with minimum 3 mil. thick plastic and secure it to valve box using duct tape or electrical tape.
- 3- Valve box shall be located in planting area.



GATE VALVE AND ANCHOR